





*recipes
inside!*

DBM150

EVERYDAY 1.5LB **BREAD MAKER**

Instruction Manual | Recipe Guide





EVERYDAY 1.5LB BREAD MAKER



Important Safeguards	4-7
Parts & Features	8-9
Bread-Making Process	11
Programs	12
Functions	14-15
Using Your Ingredient Dispenser	16-17
Using Your Bread Maker	18-27
Cleaning & Maintenance	28
Troubleshooting	29
Recipes	31-51
Notes.....	52-53
Customer Support.....	54
Warranty.....	55


the dash team!

IMPORTANT SAFEGUARDS

IMPORTANT SAFEGUARDS: PLEASE READ AND SAVE THIS INSTRUCTION AND CARE MANUAL.

When using electrical appliances, basic safety precautions should be followed, including:

- Read all instructions.
- Before using check that the voltage of wall outlet corresponds to that shown on the rating plate.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or it is dropped or damaged in any manner. Return the appliance to manufacturer or the nearest authorized service agent for examination, repair or electrical or mechanical adjustment.
- Do not touch hot surfaces.
- To protect against electric shock do not immerse cord, plugs, or housing in water or other liquid.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Do not let cord hang over edge of table or hot surface.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- The appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised.
- Keep the appliance and its cord out of reach of children less than 8 years.
- For maintenance, other than cleaning, please contact StoreBound directly at 1-800-898-6970 from 7AM-7PM PT Monday-Friday or by email at support@bydash.com.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Do not touch any moving or spinning parts of the machine when baking.
- Never switch on the appliance without properly placed Baking Pan filled with ingredients.
- Never beat the Baking Pan on the top or edge to remove the pan as this may damage the Baking Pan.
- Metal foils or other materials must not be inserted into the bread maker as this can give rise to the risk of a fire or short circuit.

IMPORTANT SAFEGUARDS

- Never cover the bread maker with a towel or any other material, heat and steam must be able to escape freely. A fire can be caused if it is covered by, or comes into contact with combustible material.
- Do not operate the appliance for other than its intended use.
- Always use the appliance on a secure, dry level surface.
- Do not use outdoors.
- The appliance is not intended to be operated by means of an external timer or separate remote-control system.
- This appliance is intended to be used in household and similar applications such as: Staff kitchen areas in shops, offices and other working environments; Farm houses; By clients in hotels, motels and other residential type environments; Bed and breakfast type environments.
- This appliance is not intended for commercial use.
- Do not operate the unit without Baking Pan placed in the chamber to avoid damaging the appliance.
- The surfaces are liable to get hot during use, do not touch hot surfaces when appliance in operation.
- Do not touch the handle of Baking Pan if it is hot, or use suitable gloves.
- Save these instructions.

IMPORTANT SAFEGUARDS: PLEASE READ AND SAVE THIS INSTRUCTION AND CARE MANUAL.

GARANTIES IMPORTANTES

GARANTIES IMPORTANTES: VEUILLEZ LIRE ATTENTIVEMENT CE MANUEL AVANT D'UTILISER L'APPAREIL.

Lors de l'utilisation d'appareils électriques, des précautions élémentaires de sécurité doivent être respectées, notamment:

- Lisez toutes les instructions.
- Avant utilisation, vérifiez que la tension de la prise murale correspond à celle indiquée sur la plaque signalétique.
- Ne faites pas fonctionner un appareil dont le cordon ou la fiche est endommagé ou après un dysfonctionnement de l'appareil, ou il est tombé ou endommagé de quelque manière que ce soit. Renvoyez l'appareil au fabricant ou à l'agent de service autorisé le plus proche pour examen, réparation ou réglage électrique ou mécanique.
- Ne touchez pas les surfaces chaudes.
- Pour vous protéger contre les chocs électriques, ne plongez pas le cordon, les fiches ou le boîtier dans l'eau ou tout autre liquide.
- Débranchez-le de la prise lorsque vous ne l'utilisez pas, avant de mettre ou de retirer des pièces et avant de le nettoyer.
- Ne laissez pas le cordon pendre du bord de la table ou d'une surface chaude.
- L'utilisation d'accessoires non recommandés par le fabricant de l'appareil peut provoquer des blessures.
- L'appareil peut être utilisé par des enfants âgés de 8 ans et plus et des personnes ayant des capacités physiques, sensorielles ou mentales réduites ou un manque d'expérience et de connaissances s'ils ont été supervisés et comprennent les risques encourus. Les enfants ne doivent pas jouer avec l'appareil. Le nettoyage et l'entretien par l'utilisateur ne doivent pas être effectués par des enfants à moins qu'ils ne soient âgés de plus de 8 ans et supervisés.
- Gardez l'appareil et son cordon hors de portée des enfants de moins de 8 ans.
- Pour la maintenance, autre que le nettoyage, veuillez contacter StoreBound directement au 1-800-898-6970 de 7 h 00 à 19 h 00 (heure du Pacifique) du lundi au vendredi ou par courriel à support@bydash.com.
- Ne pas placer sur ou à proximité d'un brûleur à gaz ou électrique chaud, ou dans un four chauffé.
- Ne touchez aucune pièce en mouvement ou en rotation de la machine lors de la cuisson.
- N'allumez jamais l'appareil sans un plat

GARANTIES IMPORTANTES

- de cuisson correctement placé et rempli d'ingrédients.
- Ne battez jamais le plat de cuisson sur le dessus ou le bord pour retirer le plat car cela pourrait endommager le plat de cuisson.
 - Les feuilles métalliques ou autres matériaux ne doivent pas être insérés dans la machine à pain car cela peut entraîner un risque d'incendie ou de court-circuit.
 - Ne couvrez jamais la machine à pain avec une serviette ou tout autre matériau, la chaleur et la vapeur doivent pouvoir s'échapper librement. Un incendie peut être provoqué s'il est couvert par ou entre en contact avec un matériau combustible.
 - N'utilisez pas l'appareil à d'autres fins que celles pour lesquelles il a été conçu.
 - Utilisez toujours l'appareil sur une surface plane et sèche.
 - Ne l'utilisez pas à l'extérieur.
 - L'appareil n'est pas destiné à être utilisé au moyen d'une minuterie externe ou d'un système de télécommande séparé.
 - Cet appareil a été incorporé avec une fiche mise à la terre. Veuillez vous assurer que la prise murale de votre maison est bien mise à la terre.
 - Cet appareil est destiné à être utilisé dans des applications domestiques et similaires telles que: les cuisines du personnel dans les magasins, bureaux et autres environnements de travail; Maisons de ferme; Par les clients des hôtels, motels et autres environnements de type résidentiel; Environnements de type chambre d'hôtes.
 - Cet appareil n'est pas destiné à un usage commercial.
 - N'utilisez pas l'appareil sans le plat de cuisson placé dans la chambre pour éviter d'endommager l'appareil.
 - Les surfaces sont susceptibles de chauffer pendant l'utilisation, ne touchez pas les surfaces chaudes lorsque l'appareil est en marche.
 - Ne touchez pas la poignée du plat de cuisson s'il est chaud ou utilisez des gants appropriés.
 - Conservez ces instructions.

GARANTIES IMPORTANTES: VEUILLEZ LIRE ATTENTIVEMENT CE MANUEL AVANT D'UTILISER L'APPAREIL.

PARTS & FEATURES



PARTS & FEATURES





BREAD-MAKING PROCESS

ABOUT THE BREAD-MAKING PROCESS

Your Bread Maker has 12 settings that cover every aspect of the bread-making process, from start to finish!



KNEADING

Combines ingredients into dough. If you have already prepared dough, be sure to choose a setting without kneading, like the "Bake" setting.

NOTE: The Bread Maker may shake while kneading. This is normal.



RISING

Allows yeast based breads to achieve perfect consistency. The Bread Maker will not appear to be baking or mixing, but the LCD Display will show that it is rising.



BAKING

The Bread Maker bakes the bread as it would in an oven. Time and temperature are set according to the program, as well as your chosen size and darkness.



KEEP WARM

Warms bread for up to 60 minutes after baking.

PROGRAMS

MENU BUTTON

The Menu Button is used to set different programs. Each time it is pressed (accompanied by a short beep) the program will change. Press the button repeatedly to select your desired program, of those listed below.

1	WHITE BREAD	Knead, rise and bake for normal bread. You may also add ingredients and toppings.
2	FRENCH BREAD	Knead, rise and bake, with a longer rise period. The bread baked in this function usually will have a crisper crust and lighter texture.
3	WHOLE WHEAT	Knead, rise and bake for whole wheat bread. With this function, it is not advised to use the delay function as this can produce poor results.
4	ULTRA-FAST	Knead, rise and bake in a shortened timespan. Usually the bread is smaller and more firm than bread baked with the normal time setting.
5	SWEET	Knead, rise and bake sweet bread. You may also add ingredients and toppings for flavor. Ideal for sweeter breads like brioche.
6	GLUTEN-FREE	Knead, rise and bake gluten-free bread. You may also add ingredients and toppings for flavor.
7	ARTISAN DOUGH	Knead and rise only for artisanal dough. Best used for breads that require a longer rise time. Dough can then be baked using the Bake function.
8	DOUGH	Knead and rise for uncooked dough, without baking. Remove the dough and use for making bread rolls, pizza, steamed bread, etc.
9	JAM	Boil jams and marmalades. Fruit or vegetables must be chopped before putting them into the Baking Pan.
10	PACKAGED MIX	Knead, rise and bake for pre-packaged Bread Maker mixes.
11	CAKE	Knead, rise and bake, with soda or baking powder.
12	BAKE	Bake only, for dough that has already been prepared. You can also use this program to increase the baking time of other settings if your bread is not yet finished.



FUNCTIONS

COLOR	With the Color Button you can select a LIGHT, MEDIUM or DARK color for the crust. Press this button to select your desired color.
SIZE	Press this button to select the loaf size of 1 lb or 1.5 lb bread. Please note the total operation time may vary with the different loaf size.
DELAY FUNCTION	<p>If you want to set a delay so your bread bakes later, use this button. Choose the delay time by pressing the (+) and (-) buttons. Please note that the delay includes baking time of the program. At the completion of the delay time that you choose, bread is ready to be served.</p> <p>To set the Delay time, first select the program and degree of browning. Then press the (+) or (-) Buttons to increase or decrease the delay time by an increment of 10 minutes. The maximum delay is 13 hours.</p> <p>NOTE: This function is not applicable for the programs Ultra Fast, Jam, and Bake.</p> <p>For time-delayed baking, do not use easily perishable ingredients such as eggs, fresh milk, fruits, vegetables, etc. as they may spoil if left for several hours.</p>
KEEP WARM	<p>Bread will be automatically kept warm by the Bread Maker's Keep Warm function for 60 minutes after baking. If you would like to take the bread out, switch the program off with the Start/Stop Button.</p> <p>Example: Now it is 8:30p.m, and you would like your bread to be ready next morning at 7 o'clock, i.e. in 10 hours and 30 minutes. Select your program, color, loaf size then press the (+) or (-) Buttons to add the time until 10:30 appears on the LCD Display. Then press the Start/Stop Button to activate this delay program.</p> <p>You can see the dot flash and the LCD Display will count down to show the remaining time. You will get fresh bread at 7:00 AM, and if you don't want to take the bread out immediately, the Keep Warm time of 1 hour will begin at 7:00 AM.</p>

MEMORY

If power supply breaks while baking, the Bread Maker will automatically resume if the shortage is for less than 10 minutes. There is no need to press the Start/Stop Button.

If the break time exceeds 10 minutes the memory cannot be kept and the Bread Maker must be restarted. If the dough is still in the kneading process when power shuts off, you can press the Stop/Start Button to restart the program entirely.

ENVIRONMENT

The machine may work well in a wide range of temperatures, but there could be a difference in loaf size between a very warm room and a very cold room. We suggest the room temperature should be between 60° - 93°F.

WARNING DISPLAY

If the display shows “HHH” accompanied by beeping sounds after the program has been started, the temperature inside is still too high and the program has to be stopped. Open the Lid and let the machine cool down for 10 to 20 minutes.

If the display shows “LLL” accompanied by beeping sounds after pressing the Start/Stop Button (except for the Bake setting), it means the temperature inside is too low. Press the Start/Stop Button, open the Lid and let the Machine rest for 10 to 20 minutes to return to room temperature.

If the display shows “EE0” after you have pressed the Start/Stop Button, the temperature sensor is disconnected. Please contact Customer Support.

USING YOUR INGREDIENT DISPENSER

The Ingredient Dispenser of the Bread Maker is easily removable so it can be rinsed and dried. To remove the Ingredient Dispenser, gently pull up to detach.

Clean the Ingredient Dispenser and Baking Pan of the Bread Maker thoroughly before first use. Once you are done cleaning, follow the instructions below to re-attach the Ingredient Dispenser.



When replacing the Ingredient Dispenser, ensure that the metal node on one side of the base is properly aligned with the node on the inside of the Bread Maker (**photo A**).



Lift the Lid of the Bread Maker and be sure the bottom of the Ingredient Dispenser is closed before adding your ingredients (**photo B**). Otherwise, add-ins will simply fall into the bread before it is ready.

USING YOUR INGREDIENT DISPENSER



Open the Ingredient Dispenser from the top to add your ingredients (**photo C**).



Add ingredients and close (**photo D**).

USING YOUR BREAD MAKER

BEFORE FIRST USE

- Please check if all parts and accessories are complete and free of damage.
- Clean all parts of the Bread Maker according to the section “Cleaning and Maintenance”.
- Set the Bread Maker to Bake and bake empty for about 10 minutes. After cooling it down clean once more.
- Dry all parts thoroughly before placing the Baking Pan in the Bread Maker.




Place the Baking Pan in the Bread Maker
(**photo A**).



Turn Removal Handle clockwise until it clicks
into place (**photo B**).

USING YOUR BREAD MAKER



Insert the Kneading Blade onto the drive shaft. **(photo C).**


It is recommended to fill holes with butter or cooking spray prior to placing the Kneading Blade, this avoids the dough sticking beneath the Blade and makes it easier to remove.



Place ingredients into the Baking Pan. Water or other liquids should be added first, then dry ingredients **(photo D)**. Always add yeast or baking powder as the last ingredient (see photo E).

NOTE: The maximum quantity of flour and yeast is 4 cups/560g flour and 2 tsp yeast.

USING YOUR BREAD MAKER



With your finger make a small indentation on one side of the flour. Add yeast to the indentation. Make sure it does not come into contact with the liquid ingredients or salt **(photo E)**.



Close the Lid gently and plug the Power Cord into a wall outlet **(photo F)**.

USING YOUR BREAD MAKER



If your recipe requires fruit and nut add-ins, you can add them to the Ingredient Dispenser at this time by unlatching the cover of the Ingredient Dispenser (**photo G**).

See full instructions for cleaning and using the Ingredient Dispenser on pages 16-17.



Press the Menu Button repeatedly until your desired program is selected (**photo H**).

USING YOUR BREAD MAKER



Press the Color Button to select the desired crust color (**photo I**).



Press the Loaf Size Button to select the desired size (1 lb or 1.5 lb) (**photo J**).

USING YOUR BREAD MAKER



Set the delay time by pressing the (+) or (-) Button. This step may be skipped if you want the Bread Maker to start immediately (**photo K**).



Press the Start/Stop Button to begin kneading and baking bread (**photo L**).

USING YOUR BREAD MAKER



For the programs White Bread, French Bread, Whole Wheat, Sweet, Gluten-Free, Ultra-Fast, and Packaged Mix, a beep will be heard during operation, after kneading. This is to let you know that fruit and nuts added to the Ingredient Dispenser have been added (photo M).

It is possible that steam will escape through the vents in the Lid during baking. This is normal.



Once baking is complete, a beep will be heard.

You can press Start/Stop Button for approx. 2 seconds to stop the process (photo N).

USING YOUR BREAD MAKER



Remove the bread using the Removal Tool to grab the handle of the Baking Pan (**photo O**). Be careful handling the Baking Pan after cooking, as it will be hot.



Use a silicone or wood spatula to gently loosen the sides of the bread from the Baking Pan (**photo P**).

CAUTION: The Baking Pan and bread may be very hot! Always handle with care and use oven mitts, or a potholder.

USING YOUR BREAD MAKER



Turn the Baking Pan upside down onto a clean surface or cooling rack and gently shake until bread falls out (**photo Q**). Cool for about 20 minutes before slicing.

IMPORTANT: The Kneading Blade may stick in the bottom of the bread loaf when removing. Make sure to remove the Kneading Blade from the loaf of bread before slicing.



If you don't press the Start/Stop Button at the end of baking, the Keep Warm function will turn on and the bread will be kept warm automatically for 1 hour (**photo R**).

If you would like to take the bread out, switch your chosen program off with the Start/Stop Button.

USING YOUR BREAD MAKER



S

When not in use or done baking, unplug the Bread Maker's Power Cord.

CLEANING & MAINTENANCE

Disconnect the machine from the power and let it cool down prior to cleaning.

BAKING PAN

Remove the Baking Pan by turning it counter-clockwise, then pulling the handle to remove it. Wipe inside and outside of Baking Pan with a damp cloth, do not use any sharp or abrasive agents, as these will damage the Baking Pan's non-stick coating. The pan must be dried completely before re-installing. Baking Pan is also dishwasher safe.

KNEADING BLADE

If the Kneading Blade is difficult to remove from the axle, fill the Baking Pan with warm water and allow it to soak for approx. 30 minutes. The Kneading Blade can then be more easily removed.

To clean the Kneading Blade, wipe it down carefully with a damp cotton cloth. Both the Baking Pan and the Kneading Blade are dishwasher safe.

Gently wipe the outer surface of the Bread Maker with a damp cloth.

Do not use any abrasive cleaners as this will damage the surface.

Never immerse the Bread Maker in water for cleaning.

Before storing the Bread Maker, ensure that it is completely cooled and dry.

Put the Kneading Blade in the Baking Pan for storage and close the Lid.

LID AND WINDOW

Clean the Lid inside and outside with a slightly damp cloth.

HOUSING

Gently wipe the outer surface of housing with a wet cloth. Do not use any abrasive cleaner to clean as this would degrade the high polish of the surface. Never immerse the housing into water for cleaning.



Before the Bread Maker is packed away for storage, ensure that it has completely cooled down, is clean and dry, and put the Kneading Blade in the drawer, and close the Lid.

TROUBLESHOOTING

PROBLEM

CAUSE

SOLUTION

Smoke comes out of the baking chamber or the vents.

The ingredients have stuck to the baking chamber or on the outside of the Baking Pan.

Unplug the Bread Maker and clean the baking compartment or the outside of the Baking Pan.

The bread goes down in the middle after baking and is moist on the bottom.

The bread was left in the pan for too long after baking.

Take bread out of the Baking Pan before the warming function has run the full time.

It is difficult to remove bread from the Baking Pan.

The bottom of the loaf is stuck to the Kneading Blade.

Clean the Kneading Blade and shaft after baking. If necessary, remove the Baking Pan from the Bread Maker and fill the Baking Pan with warm water and let sit for 30 minutes.

The ingredients are not mixed or the bread is not baked correctly.

Incorrect program setting.

Check selected menu and other settings.

The Start/Stop Button was touched while baking.

Do not use the ingredients and start over again.

The rotation of the Kneading Blade was blocked.

Check that the Kneading Blade is not blocked by removing it. Remove the Baking Pan and make sure that the drivers turn. If not, contact Customer Service.

The appliance does not start. The Display shows HHH.

The Bread Maker was used too recently.

Unplug the Bread Maker, remove the Baking Pan, and let both cool. Then try again.



- 1 WHITE BREAD
- 2 SWISS BREAD
- 3 WHOLE WHEAT
- 4 ARTISAN DOUGH
- 5 SWEET
- 6 GLUTEN FREE
- 7 DOUGHFAST
- 8 DOUGH
- 9 RAK
- 10 UNPACKED PAK
- 11 CAKE
- 12 BAKE

DASH

RECIPE GUIDE



Follow us!

@bydash | recipes, videos, & inspiration

@unprocessyourfood | veg & vegan-friendly meals



WHITE BREAD

Ingredients:

	1 lb	1.5 lb
water, room temperature (70°F)	¾ cup	1 cup + 2 tbsp
unsalted butter, room temperature	1½ tbsp	2 tbsp + 1 tsp
sugar	1½ tsp	2 tsp
kosher salt	¾ tsp	1¼ tsp
bread flour or unbleached all-purpose flour	2 cups	3 cups
nonfat dry milk powder	2 tbsp	3 tbsp
active dry yeast	¾ tsp	1 tsp

Directions:

1. Place all the ingredients, in the order listed, into the Baking Pan fitted with the Kneading Blade. Click the Baking Pan into the Everyday 1.5lb Bread Maker.
2. Plug in the Bread Maker. Press the MENU button to select **White Bread**, COLOR: **Medium**, LOAF SIZE: **1 lb or 1.5 lb**. Press **START/STOP** to begin the bread-making process.
Tip: For making sandwiches, try the **LIGHT** setting that gives a softer crust.
3. At 8-10 minutes into the knead cycle, check the dough. It should feel tacky but not cling to your fingers. If it feels dry or hard, add water, 1 tsp at a time; if it's very sticky, add flour 1 tbsp at a time.



4. When 10 beeps sound the end of the second rise, check the dough. If doubled in size, press a finger into the dough near a corner. If it springs back, it needs more rising. Check again in 15 to 20 minutes. If the indentation holds and more than 15 minutes remain until baking starts, gently pull the dough away from the sides of the Bread Pan to deflate it by a third.
5. When the Bread Maker cycle is complete, remove the Bread Pan from the Bread Maker. Transfer the bread to a wire rack to cool completely before slicing. Unplug Bread Maker.

To Prepare Bread Using the Ultra-Fast Program

1. Prepare the ingredients for the 1 lb or 1.5 lb loaf, replacing the yeast with $\frac{3}{4}$ tsp fast-acting yeast.
2. Plug in the Bread Maker. Press the MENU button to select **Ultra-Fast** program. Press **START/STOP** to begin the bread-making process.



Packaged Mixes

Some bread machine mixes use the **Packaged Mix** setting. Use the 1.5 lb setting for mixes calling for 2 lb setting.



FRENCH BREAD

<i>Ingredients:</i>	1 lb	1.5 lb
water, room temperature (70°F)	⅔ cup	1 cup
olive oil	2 tsp	1 tbsp
sugar	1 tbsp sugar	1½ tbsp
kosher salt	½ + ⅛ tsp	1¼ tsp
bread flour or unbleached all-purpose flour	2 cups	3 cups
active dry yeast	1 tsp	1 tsp

Directions:

1. Place all the ingredients, in the order listed, into the bread pan fitted with the Kneading Blade. Click the Bread Pan in place in the Bread Maker.
2. Plug in the Bread Maker. Press the MENU button to select **French Bread**, LOAF SIZE: **1 lb. or 1.5 lb.** Press **START/STOP** to begin the bread-making process.
3. At 8-10 minutes into the knead cycle, check the dough. It should feel tacky but not cling to your fingers. If it feels dry or hard, add water, 1 tsp at a time; if very sticky, add flour 1 tbsp at a time.
4. When 10 beeps sound the end of the second rise check the dough. If doubled in size, press a finger into the dough near a corner. If it springs back, it needs more rising. Check again in 15-20 minutes. If the indentation holds and more than 15 minutes remain until baking starts, gently pull the dough away from the sides of the Pan to deflate it by a third.
5. When the cycle is complete, remove the Bread Pan from the machine. Transfer the bread to a wire rack to cool completely before slicing. Unplug the Bread Maker.

TIP: The milder taste of olive oil is recommended for this bread.



WHOLE WHEAT BREAD

Ingredients:

	1 lb	1.5 lb
water, room temperature (70°F)	¾ cup	1 cup + 2 tbsp
unsalted butter, at room temperature	1 tbsp	1 tbsp
sugar	2 tsp sugar	1 tbsp
kosher salt	¾ tsp	1 tsp
whole wheat flour	1 cup	1½ cups
bread flour or unbleached all-purpose flour	1 cup	1½ cups
nonfat dry milk powder	3 tbsp	¼ cup
active dry yeast	1 tsp	1 tsp

Directions:

1. Place all the ingredients, in the order listed, into the bread pan fitted with the Kneading Blade. Click the Bread Pan in place in the Bread Maker.
2. Plug in the Bread Maker. Press the MENU button to select **Whole Wheat**, COLOR: **Medium**, LOAF SIZE: **1 lb. or 1.5 lb.** Press **START/STOP** to begin the bread-making process.
3. At 8 to 10 minutes into the knead cycle, check the dough. It should feel tacky but not cling to your fingers. If it feels dry or hard, add water, 1 tsp at a time; if very sticky, add flour 1 Tbsp at a time.
4. When 10 beeps sound the end of the second rise check the dough. If doubled in size, press a finger into the dough near a corner. If it springs back, it needs more rising. Check again in 15-20 minutes. If the indentation holds and more than 15 minutes remain until baking starts, gently pull the dough away from the sides of the Pan to deflate it by a third.
5. When the Bread Maker cycle is complete, remove the Bread Pan from the machine. Transfer the bread to a wire rack to cool completely before slicing. Unplug Bread Maker.

TIP: For a more tender crumb and lighter flavor, use stone-ground whole wheat flour.



BRIOCHE LOAF

Ingredients:

	1 lb	1.5 lb
whole milk, room temperature (70°F)	¼ cup + 2 tbsp	½ cup + 1 tbsp
unsalted butter, softened, divided	5 tbsp	6½ tbsp
large eggs, room temperature, lightly beaten	2	3
nonfat dry milk powder	1 Tbsp	1½ tbsp
sugar	4 tsp	1 tbsp
kosher salt	1 tsp	¾ tsp
unbleached all-purpose flour	2 cups + 1 tbsp	3 cups
active dry yeast	1 tsp	1¼ tsp

Directions:

1. Place all the ingredients, in the order listed, into the Bread Pan fitted with the Kneading Blade. Click the Bread Pan in place in the Bread Maker.
2. Plug in the Bread Maker. Press the MENU button to select **Sweet**, COLOR: **Medium**, LOAF SIZE: **1 lb. or 1.5 lb.** Press **START/STOP** to begin the bread-making process.
3. At 8-10 minutes into the knead cycle, check the dough. It should feel tacky but not cling to your fingers. If it feels dry or hard, add water, 1 tsp at a time; if very sticky, add flour 1 tbsp at a time.
4. When 10 beeps sound the end of the second rise check the dough. If doubled in size, press a finger into the dough near a corner. If it springs back, it needs more rising. Check again in 15-20 minutes. If the indentation holds and more than 15 minutes remain until baking starts, gently pull the dough away from the sides of the pan to deflate it by a third.
5. When the Bread Maker cycle is complete, remove the Bread Pan from the machine. Transfer the bread to a wire rack to cool completely before slicing. Unplug Bread Maker.



 *Chef Tip!*

Cut the butter into ½-inch pieces to help it incorporate more easily.

Cut Loaf crosswise for square slices that make heavenly French toast.



GLUTEN-FREE SANDWICH BREAD

<i>Ingredients:</i>	1.5 lb
warm whole milk (90°F)	1 cup
soft unsalted butter	4 tbsp
large eggs, room temperature, beaten	4
sugar	3 tbsp
kosher salt	1¼ tsp
gluten-free all purpose flour	3 cups + 3 tbsp
xanthan gum	1¼ tsp
instant yeast	2 tsp

Directions:

1. Place the milk, butter, eggs, sugar, and salt into the Bread Pan fitted with the Kneading Blade. Add the gluten-free flour. Sprinkle the xanthan gum over the flour. Make little indentation and place the yeast in it. Secure the Bread Pan in place in the Bread Maker.
2. Plug in the Bread Maker. Press the MENU button to select **Gluten-Free**, COLOR: **Medium**. Press **START/STOP** to begin the bread-making process.
3. At 5 and 10 minutes after the Kneading Blade starts rotating, check and push any ingredients from the corners into towards the paddle so they get mixed in.
4. When the cycle is complete, remove the Bread Pan from the Bread Maker and transfer the bread to a wire rack to cool completely before slicing. Unplug Bread Maker.

NOTE: For gluten-free flour, pick one that works with yeast. If it contains xanthan gum, do not add more. Those made with dried bean flour, such as chick pea or fava, are harder to digest, may taste "beany" and makes heavier results.





COUNTY FRENCH BREAD WITH OLIVES & ROSEMARY

Ingredients:

	1 lb	1.5 lb
water, room temperature (70°F)	¾ cup	1 cup + 2 tbsp
extra virgin olive oil	1½ tsp	2¼ tsp
salt	¾ tsp	1¼ tsp
honey	½ tsp	1 tsp
finely chopped fresh rosemary	1 tsp	1½ tsp
bread flour	1¾ cups	2¼ cups + 2 tbsp
whole wheat flour	½ cup	¾ cup
rye flour	3 tbsp	¼ cup
active dry yeast	1 tsp	1¼ tsp
pitted Kalamata olives, halved and blotted very well	½ cup	¾ cup

Directions:

1. Place all the ingredients, except the olives, in the order listed, into the Bread Pan fitted with the Kneading Blade. Click the Bread Pan in place in the Bread Maker.
2. Plug in the Bread Maker. Add halved olives to the Ingredient Dispenser. Press the MENU button to select **French Bread**, LOAF SIZE: **1 lb. or 1.5 lb.** Press **START/STOP** to begin the bread-making process.
3. At 8-10 minutes into the knead cycle, check the dough. It should feel tacky but not cling to your fingers. If it feels dry or hard, add water, 1 tsp at a time; if very sticky, add flour 1 tbsp at a time.

4. When 10 beeps sound the end of the second rise check the dough. If doubled in size, press a finger into the dough near a corner. If it springs back, it needs more rising. Check again in 15-20 minutes. If the indentation holds and more than 15 minutes remain until baking starts, gently pull the dough away from the sides of the pan to deflate it by a third.
5. When the Bread Maker cycle is complete, remove the Bread Pan from the machine. Transfer the bread to a wire rack to cool completely before slicing. Unplug Bread Maker.

Chef Tip!



To blot the olives thoroughly, place in one layer between double sheets of paper towel and press very firmly. Repeat 3-4 times.

Serve accompanied by a dish of extra virgin olive oil for dipping.





FOCACCIA

Ingredients: Makes 4 servings

1 cup + 2 tbsp water,
room temperature (70°F)

¼ cup extra virgin olive oil, divided

2¼ tsp Italian herb mix

1½ tsp kosher salt

3 cups + 3 tbsp bread flour or
unbleached all-purpose flour

1¼ tsp active dry yeast

2-3 tsp Fleur du sel or coarse salt

Directions:

1. Put all ingredients, in the order listed, into Bread Pan fitted with Kneading Blade. Secure the Bread Pan into the Bread Maker.
2. Plug in the Bread Maker. Press the MENU button to select **Dough**. Press **START/STOP** to begin the bread-making process.
3. Set a rack in the center of the oven. Preheat the oven to 450°F. Brush an 8x12x ½" baking dish or 15x10" jellyroll pan with 1 tbsp of the oil (see tip on page 35).
4. When the cycle is complete, place the dough in the prepared pan. With your fingers, push and press dough to fill the pan. Cover the pan loosely with plastic wrap. Set the pan in a warm place until the dough doubles in volume.
5. With a fingertip, poke dimples at 1" intervals all over the dough. Drizzle the remaining oil over the top. Sprinkle the coarse salt over the top.
6. Bake the Focaccia for 20 to 25 minutes, until it is golden brown and crusty. Transfer to a wire rack to cool in the Bread Pan. Cut the Focaccia into squares and serve.



Chef Tip!



An 8x12x½-inch baking pan makes Focaccia thick enough to split for sandwiches, especially if using bread flour. A jellyroll pan makes it thinner and extra crusty.

Grated pecorino cheese or coarsely chopped pitted olives and thyme leaves are good toppings to add, if desired.



PIZZA DOUGH

Ingredients: Makes 1.5 lb dough, four 10-inch pizzas

- 1 cup water, room temperature (70°F)
- 1½ tbsp extra virgin olive oil
- 1½ tsp kosher salt
- 3 cups + 3 tbsp unbleached all-purpose flour
- 1 tsp active dry yeast

Directions:

1. Put all ingredients, in the order listed, into Bread Pan fitted with Kneading Blade. Secure the Bread Pan into the Bread Maker.
2. Plug in the Bread Maker. Press the MENU button to select **Dough**. Press **START/STOP** to begin the bread-making process.
3. When the cycle is complete, remove the dough and follow your favorite pizza recipe. Tightly wrap the dough in plastic wrap keeps in the refrigerator for up to 36 hours.



Refrigerating pizza dough overnight, develops fuller flavor.



PIZZA MARGHERITA

Ingredients: Makes 4 10-inch pizzas

- 1 pizza dough recipe (See page 44)
- 2 cups pizza sauce, prepared or homemade tomato sauce
- 4 oz. fresh mozzarella cheese, cut into 12 slices
- 8-16 fresh basil leaves

Directions:

1. Set a rack in the lower third of the oven. If using a pizza stone, set it on the rack. Preheat the oven to 450°F.
2. Punch down the prepared pizza dough. Divide it into 4 equal pieces. Place dough on a sheet pan, cover loosely with plastic wrap, and set in a warm place until the dough doubles in size, about 30 minutes.
3. Sprinkle cornmeal on a work surface. Gently pat, pull and stretch a piece of dough into a 10-inch circle. Sprinkle a rimless cookie sheet with cornmeal. Carefully transfer the circle onto the cookie sheet. Top the dough with ½ cup of the sauce, spreading it within ½-inch of the edge using the back of a spoon. Add 3 slices of cheese.
4. Bake until the dough is crisp and browned, about 10 minutes or use the baking sheet like a pizza peel, slide the pizza onto the hot pizza stone and bake until crisp, about 8 minutes.
5. To bake multiple pizzas at the same time, place oven racks in the upper and lower third of the oven. Shape the dough into 4 circles, transferring two each to two cornmeal-sprinkled sheet pans. Top with sauce and cheese, then positioning pans on opposite sides of the oven, bake as above.
6. Top baked pizzas with fresh basil leaves. Serve and enjoy.



ICED CINNAMON SWIRL ROLLS

Ingredients:

½ cup reduced fat milk, room temperature (70°F)

2 large eggs, room temperature, beaten

4 tbsp unsalted butter, soft but still holding shape

⅓ cup sugar

¾ tsp kosher salt

1 tsp pure vanilla extract

3 cups bread flour or 3 cups + 3 tbsp unbleached all-purpose flour

⅓ cup cornstarch

1¼ tsp active dry yeast

3 tbsp unsalted butter, melted

⅓ cup lightly packed brown sugar

3 tbsp granulated sugar

2 tsp ground cinnamon

Icing:

1 cup confectioners' sugar

1½ tbsp butter, very soft

½ tsp pure vanilla extract

¼ tsp lemon juice

4 tsp reduced fat milk

Directions:

1. Put all the dough ingredients, in the order listed, into Bread Pan fitted with Kneading Blade. Click the Bread Pan into the Bread Maker.
2. Plug in the Bread Maker. Press the MENU button to select **Dough**. Press **START/STOP** to begin the bread-making process.
3. Meanwhile, in a small bowl, combine the brown sugar, granulated sugar and cinnamon, and set aside.

4. When the cycle is complete, transfer the dough to a lightly floured work surface and punch it down. Divide the dough into two equal pieces. Let the dough sit, covered loosely with plastic wrap, for 20 minutes.
5. Preheat the oven to 350°F. Brush a 13x9" baking dish with 1 tablespoon of the melted butter.
6. Roll or pat and pull each piece of dough into a 13" wide rectangle ½" thick. Brush generously with melted butter, leaving a 1" border across the long edge farthest from you. Sprinkle the cinnamon sugar filling on evenly, leaving the border at the top uncovered. Starting at the edge nearest you, roll the dough up, pulling towards you as you work to make a tight roll. Pinch the dough along the long side to seal the roll. With a serrated knife, cut each roll into 9 pieces.
7. Stand the pieces in the prepared pan, cut side down, evenly spaced. Cover loosely with plastic wrap and set the pan in a warm place until the rolls double in size, about 30 minutes.
8. Bake for 25 to 30 minutes, until the tops of the rolls are golden brown. Set the pan on a wire rack for 30 minutes.
9. While the rolls cool, for the icing, in a bowl use a wooden spoon to combine the confectioners' sugar, butter, vanilla and lemon juice. Add the milk, a teaspoon at a time, until the mixture is smooth.
10. With a fork, drizzle the icing over the rolls. Leave the rolls in the pan until the icing sets, 1 hour. Serve, or cover with plastic wrap and leave on the counter. These rolls keep well for 2 days, at room temperature.



To ice more heavily, remove cooled rolls from the baking pan. One at a time, dip the tops into the bowl of icing.

Bread flour makes light, airy rolls, and all-purpose flour makes them more dense and chewy.



BANANA WALNUT BREAD

Ingredients: **Makes 8 servings**

½ cup buttermilk, room temperature

8 tbs (1 stick), unsalted butter,
room temperature

2 large eggs, room temperature, beaten

1 tsp pure vanilla extract

3 medium-sized ripe bananas OR
1 cup mashed ripe banana

¾ tsp kosher salt

1 cup sugar

2 cups unbleached all-purpose flour

1 tsp baking soda

¾ tsp baking powder

⅔ cup walnuts, coarsely chopped

Directions:

1. Place all the ingredients, in the order listed, into the Bread Pan fitted with the Kneading Blade. Secure the Bread Pan in place in the Bread Maker.
2. Plug in the Bread Maker. Press the MENU button to select **Cake**. Press **START/STOP** to begin the bread-making process.
3. While the batter is mixing, check and, if necessary, scrape the sides of the Bread Pan with a flexible spatula to help the ingredients blend in fully.
4. When the cycle is complete, remove Banana Walnut Bread from the Bread Pan and place it on a wire rack. Cool completely before slicing.



 *Chef Tip!*

Spread slices with cream cheese, almond butter, or serve toasted.



STRAWBERRY JAM

Ingredients: Makes 3½ cups

4 cups, about 1 lb, ripe fresh strawberries, hulled and halved or quartered

1 cup sugar

4 tbsp powdered fruit pectin

1 tbsp fresh lemon juice

Directions:

1. In a food processor, pulse the strawberries until coarsely chopped.
2. Put all the ingredients, in the order listed, into the Bread Pan fitted with Kneading Blade. Secure the Pan into the Bread Maker. Plug in the Bread Maker.
3. Press the MENU button to select **Jam**. Press **START/STOP** to begin the jam-making process.
4. When the cycle is complete, open the Lid and cool the jam in the pan for 30 minutes.
5. Spoon the preserves into clean, dry jars. Cool the preserves completely on the counter, then cover. Store in the refrigerator for up to 3 weeks.



Cooling part way in the baking pan helps jam and preserves to set.



GINGER PEAR PRESERVES

Ingredients: Makes 3 cups

1 tbsp fresh lemon juice

1¾ pounds ripe Bartlett pears,
about 4 medium-sized pears

1 tsp grated fresh ginger

1 cup sugar

¼ cup powdered fruit pectin

2 tbsp finely chopped candied ginger

⅛ tsp salt

Directions:


1. Place the lemon juice in a medium bowl. Peel, core and chop the pears into pieces ½" or smaller, adding them to the bowl and tossing them with the lemon juice as you work to keep them from turning brown.
2. Put all the ingredients, in the order listed, into the Bread Pan fitted with Kneading Blade. Secure the Pan into the Bread Maker. Plug in the machine.
3. Press the MENU button to select **Jam**. Press **START/STOP** to begin the jam-making process.
4. When the cycle is complete, open the lid and cool the Ginger Pear Preserves in the pan for 30 minutes.
5. Spoon the preserves into clean, dry jars. Cool the preserves completely, then cover. Store in the refrigerator for up to 3 weeks.

CUSTOMER SUPPORT

**FEEL GOOD
GUARANTEE™**

Dash values quality and workmanship and stands behind this product with our Feel Good Guarantee™. To learn more about our commitment to quality, visit bydash.com/feelgood.

Our customer support teams in the US and Canada are at your service Monday - Friday during the times below.
Contact us at **1 (800) 898-6970** or support@bydash.com



Hey **Hawaii!** You can reach our customer service team from **3AM to 3PM**.
And also, **Alaska**, feel free to reach out from **5AM to 5PM**.

STOREBOUND, LLC – 1 YEAR LIMITED WARRANTY

Your StoreBound product is warranted to be free from defects in material and workmanship for a period of one (1) year from the date of the original purchase when utilized for normal and intended household use. Should any defect covered by the terms of the limited warranty be discovered within one (1) year, StoreBound, LLC will repair or replace the defective part. To process a warranty claim, contact Customer Support at 1-800-898-6970 for further assistance and instruction. A Customer Support agent will assist you by troubleshooting minor problems. If troubleshooting fails to fix the problem, a return authorization will be issued. Proof of purchase indicating the date, model number, serial number and place of purchase is required and should accompany the return. You must also include your full name, shipping address, and telephone number. We are unable to ship returns to a PO box. StoreBound will not be responsible for delays or unprocessed claims resulting from a purchaser's failure to provide any or all of the necessary information. Freight costs must be prepaid by the purchaser.

Send all inquiries to support@bydash.com.

There are no express warranties except as listed above.

Warranty is voided if used outside of the 50 states of the United States, the District of Columbia or the 10 provinces of Canada. Warranty is voided if used with an electric adapter/converter or used with any voltage plug other than 120V.

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CUSTOMER. STOREBOUND SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES OR FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT EXCEPT TO THE EXTENT REQUIRED BY APPLICABLE LAW. ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY.

Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts. Therefore, the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

Refurbished items or items not purchased through an authorized retailer are not eligible for warranty claims.

REPAIRS

DANGER! Risk of electric shock! The Dash Everyday 1.5lb Bread Maker is an electrical appliance.

Do not attempt to repair the appliance yourself under any circumstances.

Contact Customer Support regarding repairs to the appliance.

TECHNICAL SPECIFICATIONS

Model: DBM150

Voltage: 120V ~ 60Hz

Power Rating: 450W

Stock#: DBM150_20200824_V4



This product has passed food safety testing in accordance with FDA guidelines.





1-800-898-6970 | @unprocessyourfood | bydash.com