


# BUTTER SPRAYER QUICKSTART GUIDE

## UNDERSTANDING YOUR INDICATOR LIGHTS

### POWER INDICATOR LIGHT (on Base of Butter Sprayer)




Butter Sprayer is powered on.



Butter Sprayer is connected to the Base.

### CHARGING/MELTING INDICATOR LIGHT (on Body of Butter Sprayer)



Butter is melting and Butter Sprayer can be used for short spraying periods.



Butter is completely melted and Butter Sprayer is ready for use.



Butter is starting to harden and needs to be heated.



Butter Sprayer is heating and butter is melting.



Low battery. Charge the Butter Sprayer.



Issue with battery. Stop use immediately and contact customer service.

#### KEY




SOLID



BLINKING

# CLEANING & MAINTENANCE

## CLEAN THE INTERIOR WITH *Hot Water*



To clean the interior of the Butter Sprayer, remove any excess butter with a nylon, silicone or rubber utensil. Once the Butter Sprayer is emptied, place it on the Charging Base with the power cord plugged in. When the Indicator Light begins flashing blue, remove the Butter Sprayer from the Charging Base, fill with hot water and spray into a sink. Repeat until the interior chamber is clean.

To prevent additional drips on the front of the Butter Sprayer, it is recommended to occasionally clean the Butter Sponge. Remove the Nozzle Cap and Butter Sponge, and wash both with warm, soapy water. Ensure that both are thoroughly dried before replacing.

Extra Sponges are included to replace your Butter Sponge as needed after longterm use or before longterm storage.

## PREVENT DRIPS BY CLEANING THE *Butter Sponge*

