

ZFENSDGR11

11" DEEP GRILLING & ROASTING PAN



To my fellow home chefs,

I am incredibly excited to bring new kitchen innovations to your home. With my Zakarian collection, we have created high quality products that will deliver pro chef results that are sure to impress.

Cheers,

For more recipes, cooking tips and products follow me @geoffreyzakarian and visit geoffreyzakarian.com

CONTENTS

Important Safeguards	. 4
About Non-Stick Cast Iron	. 6
Proper Usage	. 7
General Cleaning	. 8
Cleaning Tough Stains & Buildup	. 8
Customer Support	. C
Warranty	. 9

IMPORTANT SAFEGUARDS

IMPORTANT SAFEGUARDS: PLEASE READ AND SAVE THIS INSTRUCTION AND CARE MANUAL.

When using electrical appliances, basic safety precautions should be followed, including:

- Use low to medium-high burner heat when cooking to avoid damage to the cookware or coating. Extended use over high heat will reduce the life of the non-stick coating.
- Hand washing is recommended and will prolong the cookware's original appearance.
- High heat may cause food to burn to the pan causing discoloration or stains. To help address any discoloration or oil buildup, clean with warm water and baking soda solution with a soft towel or sponge.
- It is recommended that you use cooking utensils made of silicone, nylon, wood, or melamine to protect the non-stick coating.
- Always use extreme caution when handling hot cookware and keep out of reach of children at all times.
- Do not let the handles extend over a hot burner. Doing so may cause the handle to become overly hot or cause damage.
- Always use oven mitts or potholders when handling cookware.
- Do not use your cookware in the microwave.



ABOUT NON-STICK CAST IRON

Geoffrey Zakarian Cookware has a unique non-stick coating that is not like other cast iron products. Follow these tips to ensure the longevity of your product:



Do not season your Zakarian Cookware with oil, as you typically would with cast iron cookware. Doing so will damage the non-stick coating.



Avoid using extra virgin olive oil over high heat as it will burn and leave a thin carbonized layer on the surface.



Aerosol cooking spray should not be used on non-stick cast iron as it damages the coating and is difficult to remove.



Cooking over a high heat burner for prolonged periods may cause staining.



If your Zakarian Cookware product has a wooden handle, it is not safe to put it in the oven.

PROPER USAGE



Preheat with oil, butter or water

Use a small amount of oil, butter or water to lightly and evenly coat the inside surface each time you cook. Do not use aerosol cooking sprays. Allow the oil to heat for a minute before adding food. Never heat your cookware empty or dry as this can result in property damage or injury.



Use low to medium heat

Use low to medium burner heat when cooking to avoid damage to the cookware or coating. Cooking over a high heat burner for prolonged periods may cause staining and/or an uneven distribution of heat.

Your cookware is oven-safe up to 500°F.

Use extreme caution when using the cookware on glass stovetops as this may scratch or damage the glass.



Non-stick safe utensils only

Silicone, nylon, or wood utensils are recommended to protect the non-stick coating. Metal utensils may scratch the non-stick coating.



Allow to cool

Always allow the cookware to cool before submerging into water or other liquids. Never put a hot pan on a cold surface such as a marble countertop. Use a trivet.

GENERAL CLEANING



Cast iron is NOT dishwasher safe.



Hand-washing with a soft towel or sponge in warm, soapy water is recommended to prolong the cookware's original appearance.



Always allow the cookware to cool before cleaning. Filling with cold water before cooling may damage the cookware.



Never use steel wool or abrasive cleaning pads, as these may scrape off the coating. Do not use harsh cleaners.

CLEANING TOUGH STAINS AND BUILDUP

Soaking

Try soaking the cookware overnight in hot, soapy water. For really tough stains like barbecue sauce, mix $\frac{1}{2}$ cup of dishwasher detergent with 2 cups of hot water. Let stand in the cookware overnight then rinse and wash thoroughly.

Solution

For some foods, simmering $\frac{1}{2}$ cup of vinegar and scrubbing with a non-abrasive sponge will give better cleaning results. Do not use metal sponges or brushes.

Buildup

To help clean any discoloration or oil buildup, clean with a solution of baking soda and warm water using a soft towel or sponge.

CUSTOMER SUPPORT & WARRANTY

DREAM TEAM IN YOUR KITCHEN

Chef Geoffrey Zakarian has teamed up with Dash, a leading manufacturer of cookware and kitchen tools, to bring you high-quality professional grade products specifically designed for home use. This collection provides a combination of innovation, craftsmanship and culinary expertise that will elevate your cooking endeavors.

CUSTOMER SUPPORT

Contact Customer Support regarding repairs to the product. We welcome and value all concerns and questions from our customers. Please do not hesitate to contact us for product support, warranty, and maintenance related questions directly at:

1-800-898-6970 from 7AM-7PM PT, Monday-Friday, or by email at zakarian@bydash.com.

Dash - 1 Year Limited Warranty

Your Zakarian product by Dash is warranted to be free from defects in material and workmanship for a period of one (1) year from the date of the original purchase when utilized for normal and intended household use. Should any defect covered by the terms of the limited warranty be discovered within one (1) year, Dash will repair or replace the defective part. To process a warranty claim, contact Customer Support at 1-800-898-6970 for further assistance and instruction. A Customer Support agent will assist you by troubleshooting minor problems, If troubleshooting fails to fix the problem, a return authorization will be issued. Proof of purchase indicating the date and place of purchase is required and should accompany the return. You must also include your full name, shipping address, and telephone number. We are unable to ship returns to a PO box. Dash will not be responsible for delays or unprocessed claims resulting from a purchaser's failure to provide any or all of the necessary information. Freight costs must be prepaid by the purchaser.

Send all inquiries to zakarian@bydash.com.

There are no express warranties except as listed above.

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CUSTOMER. DASH SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES OR FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT EXCEPT TO THE EXTENT REQUIRED BY APPLICABLE LAW. ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY.

Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts. Therefore, the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.



This product has passed food safety testing in accordance with FDA quidelines.







PLEASE NOTE: NON-STICK CAST IRON COOKWARE IS NOT DISHWASHER-SAFE

ZFENSDGR11_IM_2020501_v6 Made in China



Ph: 1-800-898-6970 | Email: zakarian@bydash.com